



# **Installation Guide** AWM-LB

# Arm Base






#### IMPORTANT INFORMATION

- ! Please ensure this product is installed as per these installation instructions.
- ! Do not remove/ throw away the plastic sleeve on the base.
- ! This product is compatible with AWM Series Arms and Fixings.
- ! The manufacturer accepts no responsibility for incorrect installation.

## 1. Attach Base to fixing (fixing sold separately)

**1.1** Follow the installation guide provided with the fixing to attach the Base and fit it to the worksurface.



#### **AWM Fixing options**



Kit

AWM-FB

**Bolt Through F Clamp** 



**Heavy Duty F Clamp** AWM-FH




C Clamp AWM-FC



**Grommet** Clamp AC-GC

# 2. (Optional) Set arm rotation to 360°

Note rotation is set to 180° by default. This will protect the wall by preventing the arm swinging into it.




2.2 To remove rotation ring press down on front edge and lift.

AWM-FF




2.3 Replace rotation ring in the desired orientation and replace plastic sleeve.



### 3. Fit arm onto Base


**3.1** Push arm onto base, grub screw must be backed off at this time.

NOTE: Ensure plastic sleeve is on shaft before fitting arm.



**NOTE:** Arm sold separately

**3.2** Ensure arm is fully pushed onto base.



3.3 Tighten set screw.



NOTE: Check the arm pan adjustment is smooth after tightening.